


INNER FAIRING - FLHT/I & FLHX/I MODELS



Ref #	Part Number	Qty	Description
1	756	6	PLUG, air deflector hole
2	2445	2	SCREW, 1/4-20 X 9/16 button hd.
3	2446	2	SCREW, 1/4-20 X 5/8 torx socket button hd.
4	2965	1	SCREW, #10 X 2 pan hd., self-tapping
	3387	1	SCREW, #10-16 X 1 torx pan hd. self tapping
5	2941	6	SCREW, 1/4-20 X 9/16 hex socket hd. self-tapping
6	2994	6	SCREW, 10-24 X 3/4 internal T27 drive
7	3612	4	SCREW
8	7688	2	NUT, 1/4-20 X 7/32 X 7/16 hex (Grade 2)
9	7900	4	CLIP NUT
10	10065	2	CABLE STRAP
11	10103	1	CLIP, adhesive backed
12	11445	2	GROMMET, throttle & clutch cables
13	11488	1	GROMMET, handlebar, right
	11492	1	GROMMET, handlebar, left
14	16585-96	5	INSERT, threaded
15	58128-96	1	AIR DEFLECTOR, right
	58129-96	1	AIR DEFLECTOR, left
16	58311-96	2	TRIM SEAL, inner fairing, 29" long
17	58478-96A	1	BRACKET, fairing support, left
18	58479-96A	1	BRACKET, fairing support, right
19	58497-96A	1	INNER FAIRING ASSEMBLY, w/ 7688 & 58311-96
	58199-06	1	INNER FAIRING ASSEMBLY
20	58510-96	1	CAP ASSEMBLY, inner fairing
21	58938-96B	1	SUPPORT, inner fairing, left
22	58939-96B	1	SUPPORT, inner fairing, right
23	70271-98	1	WIRE HARNESS ASM., inner fairing cap, w/ 10, 26, 27, 28, 30,...
24	70279-98	1	WIRE HARNESS ASM., inner fairing cap, w/ 10, 27, 28, 29, 30, 3...
25	70321-06	1	WIRE HARNESS ASM., inner fairing cap, w/ 10, 26, 27, 30, & 31
26	71431-96	3	PLUG, switch hole
27	71434-96A	2	BRACKET, switch
28	71505-96	1	SWITCH, lamp, w/ 73191-96
29	71513-98	1	SWITCH, cruise control, w/ 73191-96 & connector
30	71535-96	1	SWITCH, accessory, w/ 73191-96
31	73162-96BK	1	SOCKET HOUSING, 12-way
32	73191-96	1	SOCKET CONTACT, #16-20 AWG (8 - DD;FF/V;KA/B 12 - FC)
33	75106-96A	2	PLUG, gauge port
34	76286-96	1	GLOVE BOX, w/ 7900
35	77046-96A	2	COVER, speaker opening
36	77092-98	1	SWITCH, speaker control, w/ 73191-96
37	91808-89	1	ELEMENT, cigarette lighter
38	91812-89	1	SOCKET, cigarette lighter
	15339-98	1	DECAL, fog lamp switch (HDI) (not illustrated) - INTERNATIONAL...